

# TELL YOUR MOTOR TO GO STOW AND DEPLOY ITSELF.

Stow, deploy, trim and operate your motor from anywhere on the boat.

It's not magic, but it's close. Riptide Ulterra features Auto Stow/Deploy and

Power Trim, and comes with i-Pilot. Fish from anywhere. Dominate everywhere.






# AUTO STOW/DEPLOY

Nothing makes fishing easier than Riptide Ulterra. Auto Stow/ Deploy lets you get your motor in and out of the water using the included i-Pilot remote.



Once your motor's in the water, Power Trim lets you easily adjust the motor depth for changing conditions, using your remote. Riptide Ulterra handles the busy work, so you can focus on fishing.







MODEL	THRUST	VOLTS	SHAFT
Riptide Ulterra 112 / i-Pilot	112 lbs.	36	72"
Riptide Ulterra 112 / i-Pilot	112 lbs.	36	60"
Riptide Ulterra 80 / i-Pilot	80 lbs.	24	60"
Riptide Ulterra 80 / i-Pilot	80 lbs.	24	54"


#### i-PILOT CONTROL

Riptide Ulterra comes standard with a special i-Pilot system that controls Auto Stow/Deploy and Power Trim. It's also got your favorite i-Pilot functions: the advanced wireless remote uses GPS to remember fishing spots and paths, and can control speed, steering, cruise control and Advanced AutoPilot.





POWER TRIM



## INTEGRATED BATTERY METER

The i-Pilot remote tells you how much juice is left in your trolling batteries, so you know how much time you have left on the water.

### MICRO REMOTE ACCESSORY

(SOLD SEPARATELY)

Works in tandem with the standard i-Pilot remote at half the size for when you want simplified, compact control of Spot-Lock, speed, steering and Advanced AutoPilot.

