# MAIESIIC

# **MARINE AND RV TV ANTENNA**













## **Product features**

Specially compatible with HDTV of various digital terrestrial signal (DVB-T,ISDB-T,DMB-T/H,ATSC) and DAB/FM radios.

The antenna is surface-treated to withstand impacts from saltwater and weather conditions

Build-in high gain and low noise amplifier, shielded for minimum interference.

Waterproof housing design made of UV resistant, injection molded ASA material with super durability.

Omnidirectional antennas receive VHF, UHF, and FM signal from every point regardless of the direction you are travelling.

The best digital terrestrial TV reception solution for your boating and caravans SMD Technology and micro-electronics makes the high quality amplifier, ensure the excellent antenna performance.





# **Technical Specification**

Frequency range: VHF: 47-230MHz UHF: 470-862MHz

Receiving range: FM/VHF/UHF

Gain: 30dB Noise figure: 3dB

Max. output level: 110dBµV

Impedance: 75Ω

Connector: F-connectors Power supply: DC 12V/24V

# **Included in Packaging:**


- 1.Antenna x 1
- 2. Lock Nut x1
- 3. Rubber Boot x1
- 4. F Connector x1
- 5. F Socket PAL Plug x1
- 6. 10M Coax TV Cable x1
- 7. Power Supply Kit x1
- 8. Instruction Manual x1




Fig.1


# Mounting the antenna:

Option 1. Use the screws to fix the antenna on the mast (Fig.1)





Option 2. Use the mensurunt brackeett included in the package) to fix the antenna (Fig. 2the boat




#### COAX TV CABLE CONNECTION

Connect the "F" male connector of the coaseiatocathode "F" female connector of the antennearathode wrubber boot to the end of the connected "F" connector. (Fig.3)



# **POWER SUPPLY CONNECTION**


Option 1: Power from AC/DC power adapter.(Fig.4) Option 2: Power from DC (Fligtte)ry. 1.Connect the cable from Antenna to power insert input.1.Connect the cable from Antenna to ippsswer input. 2. Connect the output connector of the ipposevier to 2. Connect the output connector of the ipposewert o DTV receivers or TVs. DTV receivers or TVs. 3. Connect the DC 12V input wires to /21/48/ 12V DC jack orinstent power 3.Connect the AC/DC adapter to th/241/2V DC jack 4.Connect the other end of the wires "+" & " -" to the 12V DC system of on the power supply unit, and plug the adapter into the power socket.



### **Operation Instruction:**

Note: For the best reception, please check the followiting scon

- 1. Keep the antenna away from the sources of interferenche lametenna away from those big power consumption devices, such as air condettievmentor, hair dryer and microwave oven...etc.
- 2. Install the antenna as high as possible: in digitable terecomption, if there are some interceptions between antenna and transmission tower, ill it can be the signal loss temporarily. So if the antenna is installed are programible, those interceptions will be reduced.



360° OMNI DIRECTION TV SIGNAL reception

Once the antenna and power supply have been installed and all cables have been properly connected, you must run a chan before watching TV in order to receive maximum programs. Run a channel scan as once the antenna is moved or the TV channel. Now you can enjoy the TV program after you finish running a channel scan.